



# **TECHNICAL DATA**

2705 CONCORD ROAD • BELLE CHASSE, LA 70037  
PHONE 504 / 392-8811 • FAX 504 / 392-2173 • [www.royalcoatings.net](http://www.royalcoatings.net)

---

## **APPLICATION TIPS FOR EasyPrime and EasyFlex**

1. Mix products by stirring slowly for 3-4 minutes, add all of Part B to the last drop by punching two holes in bottom of can.
2. Product should be 70-80°F prior to mixing for best atomization.
3. You should use: 56:1 airless – tip #17 for EasyPrime; tip #21 for EasyFlex – up to 200 ft. (3/8" hose) with whip.
4. You should be ready to spray when mixed as the pot life is approximately 1 hour – higher paint temperature will shorten pot life.
5. The best results in application are achieved when the surface is dry and moisture is removed from ballast tanks by dehumidification. Drips, runs or sags are not a concern because there is no solvent entrapment possible.
6. Always use new product in its own container; don't add to existing mixed product.
7. Clean up with EZ-Solv. When you have sprayed EasyFlex or EasyPrime for 1 hour and 15 minutes you should clean the line and pump by pumping a solvent cleaner, preferably EZ-Solv, through the line and pump until clear. Then resume spraying.
8. EasyFlex may be brushed, sprayed or rolled on top of EasyPrime after EasyPrime is tacky.
9. Maximum recoat time of EasyPrime or EasyFlex is 3 – 4 weeks with temperature of 72°F.

rv: 07/09